

# Powermax30® Air

## Air T30 hand torch consumables



Minimum order quantity			1	1	5	5	1
Consumable type	Torch type	Amperage	Shield/deflector	Retaining cap	Nozzle	Electrode	Swirl ring
Drag-cutting	Hand	15-30	420399	420135	420134	420132	420133
					Combination kit 428350 <sup>1</sup>		

<sup>1</sup>Kit contains 2 standard nozzles (420134) and 2 electrodes (420132)



# Air T30 hand torch parts




## Air T30 hand torch parts

You can replace the entire hand torch and lead assembly, or you can replace individual torch components.

Item	Kit/Part number	Description
	428393 <sup>1</sup>	Kit: Air T30 hand torch assembly with 4.6 m (15 foot) lead
1	228109	Kit: Torch cap-sensor switch
2	428162	Kit: Torch start switch
3	428394	Kit: Air T30 torch body (includes o-ring)
4	428179	Kit: Replacement o-rings for torch body
5	428156	Kit: Torch trigger and spring
6	428182	Kit: Replacement springs for torch trigger
7	428381	Kit: Air T30 torch handle (includes handle screws)
8	428181	Kit: Air T30 torch replacement handle screws
9	428176	Kit: Air T30 torch lead, 4.6 m (15'), with strain relief

<sup>1</sup>Assembly includes consumables.



See pages 50-51 for current system part number information.